

RGB LED Strip Kit IR – Instruction Manual

What's Included:

1x RGB LED Strip Light

1x IR Remote Control (with battery)

1x IR Receiver 1x Power Supply (12V DC)

Installation Instructions:

Clean the surface where the LED strip will be mounted. Ensure it is dry and dust-free. Peel off the adhesive backing from the LED strip. Stick the LED strip onto the desired surface, pressing firmly to ensure it adheres well. Connect the strip to the IR receiver. Ensure the arrows on the connectors align. Plug the IR receiver into the power supply. Connect to mains power and use the remote to operate.

🔧 Note: The strip can be cut every 6 LEDs (10cm) at marked cut points. Only cut when powered off. After cutting, additional accessories are required to reconnect the strip.

Remote Control Functions:

Power On/Off Brightness Adjustment 16 Colour Presets DIY Colour Options Flash / Strobe / Fade / Smooth Modes Speed Adjustment for Dynamic Modes

📌 Ensure the remote is pointed directly at the IR receiver with no obstructions.

Safety Information:

For indoor use only using the IP65-rated splash-proof version. Do not expose the power adapter or controller to water. Do not overload the LED strip. Exceeding the maximum length can cause overheating. Always ensure correct polarity when connecting components. Unplug the power when installing, cutting, or handling the strip.

Troubleshooting: Issue Solution Strip doesn't light up Check connections and ensure correct polarity. Only some colours work Verify proper connection between strip and controller. Remote not responding Replace battery and ensure it's pointed at the IR receiver. Flickering lights Check for secure power supply and avoid overloading the strip.

Contact & Support:

If you have any questions or need further assistance, please contact our support team at:

Email: enquiries@striptecuk.com

Phone: +44 (0)1772 288931

Website: www.striptecuk.com



STRIP TEC UK LTD
BESPOKE LED STRIP - SEE THE LIGHT!
www.striptecuk.com